



Raise return vent as high as possible under the drain board. Use 2 - 45 degree fittings and one long radius elbow to make loop.

Install long sweep fittings below floor and run horizontally to nearest partition.

Use 45 degree fittings for easy stoppage cleaning.

Cleanouts required at drainage pipe below sink and in wall of foot vent.

K:\BuildingDev\Office Survey\Drafting\ARCHIVE\BID\Typical Sewage Disposal Design.dwg

Kern County Public Works
 Building & Development
 Building Inspection Division
 2700 M Street, Suite 100
 Bakersfield, CA. 93301 (661) 862-8650

**ISLAND SINK
 INSTALLATION**

2016
 CPC
 1/1/17